









Instalation manual
ALEX: Pencil-case


Pencil-case




Element symbol	Dimensions			Code	Package
1	1908	354	16	A - 105	1/1
2	1908	354	16	A - 106	1/1
3	440	355	16	A - 203	1/1
4	440	355	16	A - 204	1/1
5	406	326	16	A - 303	1/1
6	406	326	16	A - 304	1/1
7	1269	400	16	A - 006	1/1
8	630	400	16	A - 007	1/1
9	1926	212	3	A - 603	1/1

[illegible]


1




3




2




4



5



6



7

