







Instalation manual

ALEX: Shelf 125







Element symbol	Dimensions			Code	Package
1	288	249	16	1 A - 109	1/1
2	288	249	16	1 A - 110	1/1
3	1240	250	16	1 A - 205	1/1
4	1240	250	16	1 A - 206	1/1
5	288	246	16	2 A - 111	1/1
6	306	1224	3	1 A - 607	1/1



16x ø16	2x s2 ø16	2x f3 ø16x50 mm	30x 11	2x n9	2x p29 ø4x60 mm
16x ø16x12mm 3/16	16x r16	4x r16 ø4x30mm	1x p21	1x z1	16x f1 ø8x50 mm





1



2



3



4

