










Installation manual

SOLO: LOZ_160




Element symbol	Dimensions	Code	Package
1	700 150 22	SN-113	1/1
2	700 150 22	SN-114	1/1
3	284 150 22	SN-115	1/1
4	284 150 22	SN-116	1/1
5	200 2000 22	SN-117	1/1
6	100 1670 22	SN-538	1/1
7	100 1670 22	SN-539	1/1
8	590 1368 16	SN-019	2/2
9	156 1368 16	SN-020	1/1
10	1880 30 25		2
11	1980 70 27		1
12	235 70 27		1
13	786 2000 20		2


14x		r3	12x		p62	6x		p36	8x		e3	1x		z1
32x		e2	10x		r10	8x		k1	2x		e27	1x		50g
24x		s2	2x		n106	2x		n34	10x		f11	32x		f1




1




3




2




4




7




8




5




6




9



11



10



12

