









Instalation manual	
ARSAL:	SZF 3D4S



ARSAL: SZF 3D4S




Element symbol	Dimensions			Code	Package	
	1	2134	584			
1	2134	584	16	1	SZF_3D4S.001	1/1
2	2134	584	16	1	SZF_3D4S.002	1/1
3	1652	396	16	1	SZF_3D4S.008	4/4
4	1652	396	16	2	SZF_3D4S.009	4/4
5	2054	80	16	2	SZF_3D4S.014	1/1
6	1360	80	16	1	SZF_3D4S.015	1/1
7	596	180	16	1	SZF_3D4S.016	2/2
8	596	180	16	1	SZF_3D4S.017	2/2
9	550	130	16	4	SZF_3D4S.018	2/2
10	550	130	16	4	SZF_3D4S.019	2/2
11	535	130	16	4	SZF_3D4S.020	1/1
12	792	60	16	1	SZF_3D4S.021	1/1
13	394	60	16	1	SZF_3D4S.023	1/1
14	1434	638	16/46	1	SZF_3D4S.027	2/2
15	596	180	16	1	SZF_3D4S.028	2/2
16	596	180	16	1	SZF_3D4S.029	2/2
17	2079	473	3	1	SZF_3D4S.024	1/1
18	2079	435	3	2	SZF_3D4S.025	1/1
19	553	552	3	4	SZF_3D4S.026	3/3
20	2054	581	16	1	SZF_3D4S.003	3/3
21	2054	581	16	1	SZF_3D4S.004	3/3
22	1678	581	16	1	SZF_3D4S.005	3/3
23	1326	581	16	1	SZF_3D4S.006	2/2
24	1202	581	16	1	SZF_3D4S.007	3/3
25	792	581	16	1	SZF_3D4S.010	2/2
26	394	581	16	3	SZF_3D4S.011	2/2
27	394	581	16	1	SZF_3D4S.012	2/2
28	360	581	16	1	SZF_3D4S.013	3/3
29	60	534	16	4	SZF_3D4S.022	1/1
30	64	1326	16	4	SZF_3D4S.038	1/1









5




7




6




8




9




11





10




12





13




14



19



17



18

